

DETAIL C
SCALE 1 / 2

DETAIL D
SCALE 1 / 2

ITEM	QTY	PARTS LIST	
		PART NUMBER	DESCRIPTION
1	1	SI1001	SCORE CARD
2	1	SI1002	TOP HOLDER
3	1	SI1003	BOTTOM HOLFER
4	3	SI1009	PLATE SPACER
5	2	SI1004	BASE STRAP
6	1	SI1010-L	LONG ROD
7	2	SI1008	SCORE CARD KNOB
8	3	H5Z 038 0400 16	MAIN BOLT 3/8-16 x 4
9	2	HNNY8Z 038 16	3/8-16 NYLOCK
10	5	SAEFY28 038	3/8 FLAT WASHER
11	1	H5Z 038 0100 16	SUPPORT BOLT 3/8-16 x 1
12	2	5163	RUBBER GROMMET
13	1	SSSC 038 0125 16	STUD (INCLUDED WITH 14)
14	1	SI1010-S	SOFT SURFACE SPIKE

ASSEMBLY INSTRUCTIONS:


Step 1- Place washer (10) on bolt (8) then place in the single hole side of the top plate, (2) slide spacer (4) over bolt then through the single hole side of the bottom plate (3) and through the scorecard (1) and thread long rod (6) on bolt (8).

Step 2- Install remaining spacers, bolts, washers and nuts through top and bottom plates and tighten all fasteners.

Step 3-Install hard surface base straps (5) with the deeper bent strap on the top side using the 1" long bolt (11) and place on hard surface.

Step 4- Install Score Card Knobs (8) then install rubber grommets (12) to secure knobs. Work hard, play hard and let us take care of the score!

Optional Step 5- For sand use, install stud (13) into threaded long rod (6), and install Soft surface Spike on to remaining stud (14) and place into the ground.

DRAWN B. Steinberg		10/9/2019			
PROGRAM #:	-----	TITLE			
CYCLE TIME:	-----	SCOREZIT ASSEMBLY			
MATERIAL	-----				
SAW LENGTH	-----	SIZE C	PART NO SCOREZIT	REV	
		SCALE 1:1	SHEET 1 OF 1		